



How to Use WLAN AP Function to Connect Solar Camera

Catalogue

Function Explanation	2
Preparation.....	3
Connection steps.....	4
1. Connect Wi-Fi	4
2. Open SDK demo tool	4
3. Open SecureCRT tool	7

Function Explanation

1. Usage scenario:

This function is only used for **Debugging** purposes, not suitable for long-term use, suitable for camera installation in inaccessible areas.



2. Coverage:

WLAN AP coverage within a radius of **100m**.

3. Effective mode:

This function is effective in **all** Power Consumption Mode.

4. Default Password


Camera Serial Number

5. Enable Rules:

The camera defaults to Maintenance Mode. In this mode, after powering on, the WLAN AP will turn on for **5 minutes**. After disconnecting from the platform, it

will open for 10 minutes, and then turn on **every 30 minutes for 10 minutes**. When a device connected to WLAN AP, the WLAN AP will not turn off.

If necessary, you can change the mode to ON, and the camera will continue to activate the WLAN AP function when there is power.



Preparation

1. An environment that can connect to an external network (For unlock camera PSH)
2. A laptop that can connect to WiFi
3. Software:

SecureCRT



SDK demo




Connection steps

1. Connect Wi-Fi

When the camera WLAN AP can be found, connect to the AP.


The WLAN AP default password is the serial number of the camera.




2. Open SDK demo tool

1. Right click to add camera, the camera IP is 192.168.8.1


How to Use WLAN AP Function to Connect Solar Camera




2. Double click to select the camera



How to Use WLAN AP Function to Connect Solar Camera





3. Enable SSH




3. Open SecureCRT tool


1. Connect the camera using SSH.



How to Use WLAN AP Function to Connect Solar Camera




2. Input debug




- Copy the debug code generated by the device to the OA-PSH unlock page to obtain the password.

(OA: <http://psh.hikvision.com.cn:8080/sso/home/page> -----PSH unlock)




- Enter debug mode

How to Use WLAN AP Function to Connect Solar Camera




5. Input *iptables -F*

This command can unlock the camera web page



6. Open the browser and enter 192.168.8.1 to access the camera web page





See Far, Go Further