

1. RTSP URL for mobile
 - a) rtsp://10.9.96.90:554/ch1/main/av_stream
 - b) rtsp://10.9.96.90:554/ch1/sub/av_stream
 - c) rtsp://admin:abcd1234@10.9.96.90:554/Streaming/Channels/101
 - d) rtsp://admin:abcd1234@10.9.96.90:554/Streaming/Channels/102
 - i. 10.9.96.90:554, the IP and port of the device
 - ii. admin:abcd1234, this parameter means the account and password of the device
 - iii. ch1, this parameter means the channel number
 - iv. main, this parameter means the main stream
 - v. sub, this parameter means the sub stream
2. which device support the RTSP
 - a) DS-MP7608HN
 - b) DS-MP3516-RH
 - c) DS-MI9605-GA
 - d) DS-MI9605-Q36
 - e) DS-MH2311
 - f) DS-MH2211
 - g) DS-MH2111
 - h) DS-MCW405
 - i) DS-MCH508
 - j) DS-MCD202-B
 - k) DS-MH2311C
3. example



03-20-2020 Fri 14:00:23

IPCamera 01

rtsp://10.9.97.90:554/ch1/sub/av_stream