

## Person arming: Face capture and track who matches the face library


 i. Go to Multi-Target-Type Detection, Set the detection area and minimum pupil distance, and then enable it.




ii. Set the arming schedule and linkage method




iii. Go to Person arming, set the Face Picture Library



iv. Add Face Picture Library



v. Import face picture and select Batch Modeling



vi. Back to person arming, set the arming schdule and linkage method

