

How to disable analog channels

Click Camera > Analog

select IP, IP camera can be connected for the selected channel

Click Apply to save the settings