

How to turn off the PoC function

Go to camera

PoC Status

Check "Off", Click Apply

Please turn off the PoC function if the camera does not support PoC, or the camera is not produced by Hikvision.