



How to use Batch Configuration Tool to import & modify face picture library for DeepinMind NVR

For importing face picture library, the configuration steps are as follows. *Steps:*

1. Add the DeepinMind NVR via IP address or SADP tab as shown below. Only the NVR in the same LAN with PC can be added.




2. Open the Facelib Config interface.




3. Select the path of face picture folder that you want to import in PC.






4. Select a path of the face template in PC and click Export button.




5. Open the template excel that you just exported and edit the information of the people.






6. Select the face library in which you want to import face pictures.




7. Select the template excel that you finished in Step 5 and click Import button.






For modifying face picture library, the configuration steps are as follows. *Steps:*

1. Select the face library that you want to modify.




2. Select a path for the face template in PC and click Export button.






3. Open the template excel that you just exported and modify the information of the people.



4. Select the template excel that you finished in Step 3 and click Import button.





First Choice for Security Professionals **HIKVISION** Technical Support**