


## How to use Park Action on Analog PTZ

This feature allows the dome to start a predefined park action (scan, preset, pattern and etc.) automatically after a period of inactivity (park time)


Iris+ OK

Iris- Cancel


### 1. Call Menu OSD, Select **System Settings**



### 2. Select **Motion Parameter**



3. Switch **Park Act** to ON state  
Switch **Park Time** to a suitable value



**Note:** Park Act won't be executed on follow situations:

- Special presets call functions or actions;
- Alarms do linkage with PTZ action.