

# How to Configure Contact List of the 2<sup>nd</sup> Generation VIS

Product:DS-KD8003-IME1, DS-KH8350-WTE1

Publisher: Dengyanan Version: V.R20190705 File: IVMS-4200 3.1.0.7



www.hikvision.com/europe product.eu@hikvision.com

### **Purpose**


Provide a guidance for contact list configuration


### Preparation

Upgrade DS-KD8003-IME1 to 190604 Upgrade DS-KD-DIS to 190520


## **Steps**

1. Add device and create group







2. Check room number of indoor station




3. Add person, enter room number in <Resident Information>. One room number can be linked to multiple persons.




4. Go to <Access Control> , add Access Group to link person with door.





#### 5. Apply to device



6. On display module, we can see "Importing".

