

## DS-K1T Series Terminal Connect to Lock

### Operation Process

- 1) Check lock type and select NC or NO wiring method.
- 2) Select corresponding port to connect
- 3) Test opening lock

### Operation Steps:

1. Check lock type and select NC or NO wiring method

For example: NC1/COM1 default for magnetic lock or anode lock, NO1/COM1 for cathode lock

2. Select corresponding port to connect.



**Note:** It's recommended to use a separate power adapter for lock.

3. Test opening lock
  - 1) Short connect exit button cable(BUTTON and GND);
  - 2) Swipe registered card.

### Suitable Models:

Model	
DS-K1T105E/M	DS-K1T105E/M -C
DS-K1T804EF/MF	DS-K1T804EF/MF -1
DS-K1T201EF/MF	DS-K1T201EF/MF -C