How to Unbind AX PRO Panel Hik-Connect

Preparation

1. DS-PWA Series AX PRO Wireless Security Control Panel（V1.2.2_build210107 or later）
2. Hik-connect（V4.12 or later）

How to Unbind AX PRO Panel Hik-Connect

1. Find the Reset Button on AX PRO Panel



2. Unbind Steps

1) Power On the Panel
2) Hik-connect Mobile and AX PRO connect to same local network.
3) **Double-Press the Panel Reset button to enter unbind mode.**
4) Select the device and click unbind button， add enter captcha code and then click the Finish, device will unbind successfully.


Results
HIKVISION
AX PRO
The device has been added to the account 8613****88.
Apply for Sharing
Unbind Device
You can unbind the device(s) first and then add them again.
You can use that account or ask the user to share the device to you.
Unbind Device
CAPTCHA Code
Finish
The device is unbound from the account.
Add Device
Hik-Connect
Cloud Service
Notification
More

See Far, Go Further