

**VSPlayer Software** 

**User Manual** 

UD03888B

### **User Manual**

COPYRIGHT © 2016 Hangzhou Hikvision Digital Technology Co., Ltd.

#### ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou Hikvision Digital Technology Co., Ltd. or its subsidiaries (hereinafter referred to be "Hikvision"). This user manual (hereinafter referred to be "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of Hikvision. Unless otherwise stipulated, Hikvision does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

### **About this Manual**

This Manual is applicable to VSPlayer Software.

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the company website

Please use this user manual under the guidance of professionals.

### **Trademarks Acknowledgement**

(<a href="http://overseas.hikvision.com/en/">http://overseas.hikvision.com/en/</a>).

**HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

### **Legal Disclaimer**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED "AS IS", WITH ALL FAULTS AND ERRORS, AND HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL HIKVISION, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL,

INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

SURVEILLANCE LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR

JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS

THE APPLICABLE LAW. HIKVISION SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS

USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS.

# **Contents**

Chapter 1 Introd	duction	4
1.1 Overview	v	4
1.2 Version H	History	4
1.3 System R	equirements	5
1.4 Conventi	ons	5
Chapter 2 Getti	ng Started	6
2.1 Running	the Software	6
2.2 Player Se	ettings	7
2.2.1	Basic Settings	7
2.2.2	Capture Settings	8
2.2.3	Hotkey Settings	9
Chapter 3 Playir	ng Video Files	10
3.1 Adding th	he Video Files	10
3.2 Playing C	ontrol	11
3.3 Synchron	nous Playback	15
3.4 Capture a	and Continuous Capture	16
3.5 Clipping t	the File	16
3.6 Convertir	ng the File Format	17
3.7 Merging	the Files	18
3.8 Media St	reaming	19
3.9 Fisheve E	Expansion	22

# **Chapter 1** Introduction

### 1.1 Overview

The VSPlayer software is a media player designed for Windows OS. With user-friendly GUI, the software provides an intuitive, convenient way for playing media file and video control, and supports multiple audio and video formats.

## 1.2 Version History

#### V7.3

#### **Added New Features:**

- RTMP protocol for media streaming.
- View the live video of device via HLS protocol.
- Display picture, temperature and fire source information on the display window.
- Support hardware decoding for live view.
- Convert the video files from H.265 format to other formats.
- The VCA information does not display when starting playing the video by default.

#### V7.2

#### **Added New Features:**

- Support fisheye expansion for playing video files of fisheye camera.
- Support setting the location modes including by timestamp and by frame in basic settings.
- Support media streaming to share the local video file, live view of device, and desktop to others in the same LAN.

#### V7.1

#### Added New Features:

- Filter the files by file name or accurate time, and locate the video by accurate time.
- New UI for video clipping and file format converting.
- The user manual is packaged into the software.
- Optimize the digital zoom, audio control and repeat A-B segment function.

#### V7.0.0

- Support playing the video files of the various kinds of devices, such as DVR, encoder, decoder, compression card, network camera, network speed dome, etc.
- Support multiple video file formats, including Hikvision H.264, standard H.264 and standard MPEG4.
- Support 1, 4, 9, 16-window division.
- Multiple languages GUI are provided.
- Capture pictures and continuous capture during playing.

- Get the file information.
- Support file clipping, file merging and file converting.
- Support watermark.
- Digital zoom.
- Accurately position the playback point by frame or time.
- Synchronous playback.
- Reverse playback.
- Display the VCA information on the video.
- Support playing encrypted file.
- Repeat between the configured two points.
- Live view via URL mode with RTSP.
- Support motion flow to provide fluent video.

## 1.3 System Requirements

Operating System: Microsoft Windows XP (32 / 64-bit) / Windows 7 (32 / 64-bit) / Windows 8

(32 / 64-bit) / Windows 10 (32 / 64-bit)

RAM: 2GB or above

### 1.4 Conventions

In order to simplify the description, we define the "VSPlayer software" as "software" in the following chapters.


# **Chapter 2** Getting Started

# 2.1 Running the Software

After installing the software, click on the desktop to run the software.

The main interface of the software is shown below. For the descriptions of the icons and buttons on the interface, please refer to *Table 2.1 Main Interface Introduction*.

**Note:** You can click English to change the language of the software.




**Table 2.1 Main Interface Introduction** 

No.	Icon/Button	Description
	+	Add the local media file to the software.
1	ā	Delete the added files.
1		Set the playing mode for the file.
	₹-	Filter the added files by file name or accurate time.
2	Open File	Display window area. You can click <b>Open File</b> to select the
	OpenTile	file for playing.
		Select file, set language, configure player settings, view the
		user manual and check the software information.
		Minimize the software.
		Maximize the software.
3	×	Exit the software.
	<b>4</b> 8	Fisheye expansion.
	<b>(</b>	Digital zoom.
	Ó	Capture the playing video.
		Continuous capture of the playing video.

Б		Click and select whether to keep the window on top of all	
	<b>—</b>	other windows.	
Display the p		Display the playing window in full-screen mode.	
		Reverse play.	
	•	Slow forward.	
	•	Frame backward.	
	<b>D</b> / <b>I</b> I	Play / pause the video.	
4		Stop playing.	
	D	Frame forward.	
	<b>&gt;&gt;</b>	Fast forward.	
	<b>⇒</b> :	Synchronous playback.	
	<b>◄</b> 》	Audio on / mute.	
	<b></b>	Set window-division.	
	=	Hide the playlist.	
5		Open files, open directory or open live view via URL mode.	
	0	Activate the window of clip, convert, merge or streaming.	

# 2.2 Player Settings

Click and select **Settings**, or select **Settings** on the right-click menu of the playing window to enter the Player Settings interface. You can set basic, capture and hotkey settings for the player.



# 2.2.1 Basic Settings

### Steps:

- 1. Click **Basic** to enter the Basic Settings interface.
- 2. Set the option for Stick on Top.

Stick on Top When Playing: Keep the window on the top of all other windows when playing

the file.

**Never Stick on Top**: Never keep the windon on the top of all other windows at any time.

**Always Stick on Top**: Always keep the windon on the top of all other windows.

3. Set the location method during playing.

**By Timestamp:** Click on the timeline to locate the image according to the timestamp.

By Frame: Click on the timeline to locate the image according to the frame.

- 4. Check **Save List File When Exit** checkbox to keep the playlist when you exit and you can get the playlist next time you open the software.
- (Optional) Check Hardware Decoding for Live View checkbox to enable decoding by hardware for live view.

It provides better decoding performance and lower CPU usage.

- 6. You can also click **Restore** to reset the parameters to the default values.
- 7. Click **Apply** to apply the settings. Or click **OK** to save the settings and exit.



## 2.2.2 Capture Settings

#### Steps:


- 1. Click **Capture** to enter the Capture Settings interface.
- 2. Select the Format for the captured picture.
- 3. Click **Browse** to set the saving path for captured pictures.
- 4. Set the continuous capture.

**Mode:** Select the mode as by time / by frame.

**Interval:** Set the time / frame interval in the range of 1 to 100 seconds / frames.

Max. Capture Number: Configure the maximum capture number in the range of 1 to 200.


- 5. You can also click **Restore** to reset the parameters to the default values.
- 6. Click **Apply** to apply the settings. Or click **OK** to save the settings and exit.



## 2.2.3 Hotkey Settings

#### Steps:

- Click Hotkey to enter the Hotkey Settings interface.
   You can view the keyboard hotkeys for the common functions of the software.
- 2. Click the text field, and you can change the hotkey as desired.
- 3. You can also click **Restore** to reset the parameters to the default values.
- 4. Click **Apply** to apply the settings. Or click **OK** to save the settings and exit.



# **Chapter 3** Playing Video Files

#### Before you start:

You should add the supported media file to the playlist of the software.

## 3.1 Adding the Video Files

The software provides two ways for adding the local video files, including adding files of the selected folder and adding files directly. And you can also open live view of device via URL mode.

### **Adding Files**

#### Steps:

1. Click in the playlist area, or click **Open File** on the playing window, or click and select **Open File**, or click and select **Open File** under **Open**.

**Note:** The **Open File** on the playing window is only available when no video is playing and the window-division is 1.

In the pop-up window, select the file for adding.
 You can also hold Shift or Ctrl key to select multiple files.

### **Adding Folders**

#### Steps:

- 1. Click besides **Open File** on the playing window and select **Open Directory**, or click and select **Open Directory**, or click and select **Open Directory** under **Open**.
- In the pop-up window, select a folder for adding.
   You can add the supported files under the folders to the software.

#### **URL Mode**

#### Steps:

- 1. Click besides **Open File** on the playing window and select **Open URL**, or click and select **Open URL**, or click and select **Open URL** under **Open**.
- 2. In the pop-up window, input the URL of the video.

*Note:* Only RTSP and HLS protocol are supported for URL mode.

• For RTSP protocol, Format: rtsp://admin:12345@172.10.7.157/Stream/Channels/101.

admin: The user name of the camera.

**12345:** The password to log in to the camera.

**172.10.7.157:** The IP address of the camera.

101: The main stream of camera 01.

For HLS protocol, Format: http://10.20.37.12:9086/8ch06la25569d.m3u8.
 You can generate the HLS URL when creating network media streaming task. For details, refer to Chapter 3.8 Media Streaming.

You should select the connection mode according to actual needs.



Right-click the file in the Playlist and the following items are available on the right-click menu. For details, refer to *Table 3.1 Right-Click Menu on Playlist Description*.

*Note:* The right-click menu varies according to different file types.

Table 3.1 Right-Click Menu on Playlist Description


Name	Description	
Play/Pause	Play/pause the file.	
Delete File	Delete the selected file(s) from the software.	
Remove Invalid File	Delete the all the invalid file of the playlist. The invalid files are marked	
	with <b>Invalid</b> .	
Clear Playlist	Delete all the files of the playlist.	
File Location	Open the folder of the file.	
Enter Key	Enter the key of the file which is encrypted.	

# 3.2 Playing Control

After adding the video files to the playlist, you can play the file and achieve the related functions to control the video playing.

The successfully added files list on the playlist panel and you can drag the file to the display window or double-click it for playing.

Note: For the encrypted files, you should enter the key in the pop-up window to play it.



You can control the video playing by clicking the provided icons. For details, refer to *Table 3.2 Playing Control*.

**Table 3.2 Playing Control** 

lcon	Description	
	Set the playing mode for the file as single, order, repeat one or repeat	
ם	all.	
	Select to filter the files by file name or accurate time. Filtering by	
₩ -	accurate time can search the video files of the configured time point.	
Play the video reversely.		
	<b>Note:</b> It is not available for the live view which accessing via URL mode	
	or after hardware decoding enabled.	
	Set playback speed as 1/2, 1/4, 1/8 or 1/16.	
<b>≪</b>	<b>Note:</b> It is not available for the live view which accessing via URL mode	
	or after hardware decoding enabled.	
	Enable reverse playback frame by frame. Click it once to go backward	
<b>5</b> 1	by one frame.	
<b></b>	Note: It is not available for the live view which accessing via URL mode	
	or after hardware decoding enabled.	
<b>&gt;</b> / <b>II</b>	Play or pause the video.	
	Thay of pause the video.	
	Stop playing.	
	Enable playback frame by frame. Click it once to go forward by one	
D	frame.	
	<b>Note:</b> It is not available for the live view which accessing via URL mode	
	or after hardware decoding enabled.	
	Set the playback speed as 2X, 4X, 8X or 16X.	
₩	<b>Note:</b> It is not available for the live view which accessing via URL mode	
	or after hardware decoding enabled.	
	Start synchronous play under multi-window mode. The files for	
	synchronous play should have overlapped time duration. Refer to	
<b>⋾</b>	Chapter 3.3 Synchronous Playback for details.	
	<b>Note:</b> It is not available for the live view which accessing via URL mode	
	or after hardware decoding enabled.	
	Turn off/on the audio. Drag the slider bar to adjust the volume. You can	
	also press the Up or Down key on your keyboard to increase or	
	decrease the volume. You can increase the volume up to 200%.  Set window division as 1*1, 2*2, 3*3 or 4*4. You can select a window	
<b>III</b>	and double-click a video file to play it. See the above figure with multi-window division.	
	Enable digital zoom. Use the mouse to draw a yellow rectangle and the	
	image within it will be enlarged. A navigation window will show and	
	you can drag the yellow rectangle to adjust its position. Click the icon	
	again to disable digital zoom.	
	You can also use the mouse wheel to zoom in or zoom out.	
	Tod can also use the mouse wheel to zoom in or zoom out.	

	Capture the playing video. Refer to Chapter 3.4 Capture and	
	Continuous Capture for details.	
	Start continuous capture of the playing video. Refer to Chapter 3.4	
Capture and Continuous Capture for details.		
	Note: It is not available after hardware decoding enabled.	
<b></b>	Select whether to keep the window on top of all other windows.	
Ħ	Display the playing window in full-screen mode.	

Or you can right-click on the playing window to access the play control menu. For details, refer to *Table 3.3 Right-Click Menu on Display Window Description*.

*Note:* By default, VCA information does not display when starting playing the video.



Table 3.3 Right-Click Menu on Display Window Description

Name	Description			
Full Screen	Display the playing window in full-screen mode.			
	Stick on Top When Playing			
Stick on Top	Never Stick on Top	Select whether to keep the window on the top of all other windows		
	Always Stick on Top	or an other windows		
	Locate by Timestamp: Input the time and the video will be played back from			
	that time.			
	Locate by Frame: Accurately position the playback point by frame.			
	Locate by Accurate Time: Locating by accurate time to play back the video of			
Play Control	the configured time point.			
riay control	First Frame: Go to the first frame of the video.			
	Last Frame: Go to the last frame of the video.			
	<b>Drop Frame:</b> Drop the frame to reduce the CPU usage.			
	Motion Flow: Enable the function to get the fluent video, especially for motion			
	image.			

	Repeat A-B Segment: Click to enable this function, and drag the A and B point			
	on the timeline to adjust the position. Then the video can repeat between the			
	configured two points.			
	For other items, please refer to the description of the related icons.			
Play Mode	Set the playing mode for the file as single, order, repeat one or repeat all.			
Mute	Turn off the audio of the file.			
mate	Image Rotation Rotate the image during playing.			
	image Notation			
	Color Adjustment	Set the parameters of saturation, hue, contrast and brightness		
	Watermark	Check the watermark information of the video.		
	vatermark			
		VCA: Display the VCA information.		
		<b>Note:</b> You should configure the VCA information for the live view which accessing		
		via URL mode. For details, refer to the <i>User</i>		
		Manual of the device.  Motion Detection: Highlight the motion of the		
		video.		
	VCA Info.	<b>Note:</b> You should configure the motion detection for the live view which accessing via		
		URL mode. For details, refer to the <i>User Manual</i> of the device.		
		POS Text Overlay: Display the POS text.		
		<b>Note:</b> This function should be supported by the		
Image Control		device and the device should be configured		
image control		with POS text overlay. For details, please refer		
		to the <i>User Manual</i> of the device.		
		Temperature: Display the detected		
		temperature.		
		<b>Note:</b> This function is only available for thermal		
		camera. For details, refer to the User Manual of		
		the thermal camera.		
		Picture Overlay: Display the picture on the		
		display window.		
		Note: You should configure the picture		
		information for the live view which accessing		
		via URL mode. For details, refer to the <i>User</i>		
		Manual of the camera.		
		Fire Source: Display the file source information.		
		<b>Note:</b> This function is only available for thermal		
		camera. For details, refer to the User Manual of		
		the thermal camera.		
A 1 D	Set the video size as original s	ize, 4:3, 16:9 or Fill Window. You can also set the		
Aspect Ratio	window size as 2X, original size	e, 1/2 or 1/4.		
Window				
Division	Set the 1/4/9/16-window division.			
	1			

Combune	Capture the playing video. Refer to Chapter 3.4 Capture and Continuous		
Capture	Capture for details.		
Continuous	Continuous capture of the playing video. Refer to Chapter 3.4 Capture and		
	Continuous Capture for details.		
Capture	Note: It is not available after hardware decoding enabled.		
Digital Zoom	Enable digital zoom of the video.		
	Clip the file to get the required video footage. Refer to Chapter 3.5 Clipping the		
Clin	File for details.		
Clip	Note: It is not available for the live view which accessing via URL mode or after		
	hardware decoding enabled.		
Comment	You can convert the files or real-time streams to other format. Refer to <i>Chapter</i>		
Convert	3.6 Converting the File for detailed configuration.		
Marian	Merge multiple files (>=2) into a single large file. Refer to Chapter 3.7 Merging		
Merge	the Files for details.		
Media	Create local, network, or desktop media streaming and generate URL to share		
	the videos to other computers and devices in the same LAN. Refer to <i>Chapter</i>		
Streaming	3.8 Media Streaming.		
	Play the video files in fisheye expansion mode. Refer to Chapter 3.9 Fisheye		
Fisheye	Expansion.		
Expansion	Note: It is not available for the live view which accessing via URL mode or after		
	hardware decoding enabled.		
Sottings	Configure the player settings, including basic, capture and hotkey settings.		
Settings	Please refer to Chapter 2.2 Player Settings for detailed information.		
File	Check the detailed information of the file, such as file name, video length, file		
Information	size, file type and resolution, etc.		

# 3.3 Synchronous Playback

#### Purpose:

You can play the video files in synchronization if they have overlapped time duration.

**Note:** This function is not available for the live view which accessing via URL mode or after hardware decoding enabled.


#### Steps:

- 1. Click and select a multi-window (2x2, 3x3 or 4X4) division.
- 2. Select a window and double-click a video file to play it.
- 3. Repeat step 2 to start playing multiple video files.
- 4. Click 

  to start synchronous play.

*Note:* The files for synchronous play should have overlapped time duration.

5. (Optional) You can drag the ■ to zoom in or zoom out the timeline bar. Click □ to adjust the playback position.



## 3.4 Capture and Continuous Capture

You can take pictures of the playing video and save them to local PC.

There are two ways available for capturing pictures, including Capture and Continuous Capture.

**Capture**: During the video playing, click to take a picture for the video. Refer to *Chapter 2.2.2*Capture Settings for the saving path and picture format of the captured pictures.

**Continuous Capture:** During the video playing, click to start continuous capture of the playing video to take pictures continuously. You can click to stop the continuous capture manually. Otherwise, the continuous capture stops after the number of captured pictures has reached the configured maximum capture number. Refer to *Chapter 2.2.2 Capture Settings* for the saving path of the captured pictures and the related parameters.

*Note:* Continuous capture is not supported after hardware decoding enabled.

## 3.5 Clipping the File

#### Purpose:

During playback, you can clip the file to get the required video footage.

**Note:** This function is not available for the live view which accessing via URL mode or after hardware decoding enabled.

### Steps:

1. During the video playing, click and select , or select Clip on the right-click menu of

the playing window to enter the Clip interface.

**Note:** For selecting **Clip** under , you should click **Open File**, or click to select a video file for clipping.

2. Drag ☐ to set the desired start and end position of the video footage. You can also click ☐ and ☐ to adjust the position.



- 3. (Optional) You can click **Preview** to view the video to clip.
- 4. Click **Browse** to set a saving path and file name for the clipped file.
- 5. Click **Clip** to clip the file.


## 3.6 Converting the File Format

#### Purpose:

You can convert the files or real-time streams to the target formats, and the parameters are configurable, such as format, encoding type, resolution, bitrate, and so on.


#### Steps:

1. Click and select, or select **Convert** on the right-click menu of the playing window to pop up the Format Converter window.




- 2. Add file(s) or real-time streams.
  - For adding file(s), select **File** tab, click **1** and select **Single Add** to add one file, or click

Batch Add to add files in batch.



For adding real-time stream, select Stream tab and click 

 to add the real-time stream.



For detailed configuration about format converting, please refer to the user manual of the Format Converter (click and select **User Manual** on the Format Converter window).

**Note:** You can convert the video files from H.265 format to other formats, but converting video files from the other formats to H.265 is not supported.

## 3.7 Merging the Files


#### Purpose:

You can merge multiple files into a single large file to view all the needed files continuously.

*Note:* This function is not supported by the live view which accessing via URL mode.

#### Steps:

- 1. Click and select nor select **Merge** on the right-click menu of the playing window to enter the Merge interface.
- Click Add to select the files from local PC.



- (Optional) Click to select a file and click ↑ or ↓ to move the file up or down to adjust its merging position.
  - You can also click **✗** to remove it from the merging list
- 4. Click **Browse** to set a saving path and file name for the merged file.
  - You can click **Open Dir.** to open the directory.
- 5. Click **Start** to start merging the files.
  - You can click **Stop** during the merging process.

## 3.8 Media Streaming

#### Purpose:


You can create local, network, or desktop media streaming task and generate URL to share the videos of local files, live view of device, or desktop to other users in the same LAN.

#### Steps:

1. Right-click on the display window area and select **Media Streaming** to open the Media Streaming tool.

Or you can click and select to open the Media Streaming tool.

**Note:** The Media Streaming tool should keep running during the whole process of media streaming.



- 2. Click **Add** button and select the media streaming type as Local, Network, or Desktop.
  - Local: Share the local video/audio file to others
     For creating the media streaming of local video/audio files:



- (1) Input the media streaming name in the Name field as you want.
- (2) Click Add button to browse and select the video/audio file from local PC.
- (3) Select the protocol type as RTSP, HLS or RTMP.

**Note:** Table 3.4 Supported Encoding Format shows the supported video/audio file encoding formats under RTSP, HLS and RTMP protocol.

Table 3.4 Supported Effecting Format			
Protocol Package Format	RTSP	HLS	RTMP
PS	Video: H.264, H.265; Audio: G711a, G711u, G722, AAC, MPEG;	Video: H.264; Audio: AAC;	Video: H.264; Audio: G711a, G711u, AAC;
RTP	Video: H.264, H.265; Audio: G711a, G711u, G722, AAC;	Video: H.264; Audio: AAC;	Video: H.264; Audio: G711a, G711u, AAC;
TS	Video: H.264; Audio: G711a, G711u, G722, AAC	Video: H.264; Audio: AAC;	Video: H.264; Audio: G711a, G711u, AAC;

**Table 3.4 Supported Encoding Format** 

- (4) Click Create to create the task and generate the media streaming URL.
- Network: Share the live view of the device to others
   For creating the media streaming of live view of device:



- (1) Input the media streaming name in the Name field as you want.
- (2) In the Source URL field, input the address of the device.

**Note:** The source URL should be a valid URL address with user name, password of the device and the corresponding protocol.

For example, the source URL can be:

#### rtsp://10.16.6.113:8487/live/ubp2195t78674q6

(3) Select the protocol type as RTSP, HLS or RTMP.

**Note:** Table 3.4 Supported Encoding Format shows the supported video/audio file encoding formats under RTSP, HLS or RTMP protocol.

- (4) Click **Create** to create the task and generate the media streaming URL.
- Desktop: Share the live image of the desktop to others
   For creating the media streaming of the current desktop:




- (1) Input the media streaming name in the Name field as you want.
- (2) Select the protocol type as RTSP, HLS or RTMP.

**Note:** Table 3.4 Supported Encoding Format shows the supported video/audio file encoding formats under RTSP, HLS or RTMP protocol.

(3) Click Create to create the task and generate the media streaming URL.

The created task with details, including name, status, protocol type, create time and URL, will display in the media streaming list as follows.



- 3. (Optional) Select the task and click X to delete it. Or you can right-click on the target task and select **Delete** to delete it.
- 4. (Optional) Select the task and click to clear all the tasks. Or you can right-click on the task and select **Clear** to clear all the tasks.
- 5. (Optional) Select the media streaming task with status as Succeeded and click Copy button to copy its URL. Or you can right-click the target task and select Copy to copy the URL. You can send the URL to others to share the local video, the live view of the device, or the desktop view. Other users can open the URL with the player which supports media streaming function to view the shared video.

## 3.9 Fisheye Expansion

#### Purpose:

You can play the fisheye camera's video files in fisheye expansion mode.

When playing the video files of the fisheye camera, you can click button to enter the Fisheye Expansion interface. Or you can right-click on the display window area and select **Fisheye Expansion** to enter the Fisheye Expansion interface.

#### **Notes:**

- This function is not available for the live view which accessing via URL mode or after hardware decoding enabled.
- The video files should be larger than 4K.
- Start playing the video file by VSPlayer before fisheye expansion.



For the introductions of play control buttons, pleases refer to *Table 3.2 Playing Control*.

#### Steps:

1. Select the mounting type.

Select ceiling mounting, wall mounting, or table mounting according to the actual mounting type you adopted for your camera.

lcon	Description		
•	Ceiling mounting.		
	Wall mounting.		
•	Table mounting.		

2. Select the display mode.

You can select a display mode for the layout of the live view window. The description of each display mode is shown in the following table.

Icon	Description	lcon	Description
	Fisheye view.	5	Dual-180 ° panorama view.
C	Panorama view.	C-	Panorama view and one PTZ view.
Ç.	Panorama view and 3 PTZ views.		Panorama view and 6 PTZ views.
	Panorama view and 8 PTZ views.		2 PTZ views.
$\blacksquare$	4 PTZ views.	Ħ	One fisheye view and 3 PTZ views.
<b>!!!</b>	One fisheye view and 8 PTZ views.	$\longleftrightarrow$	Panorama view for wall mounting.
$\rightleftharpoons$	Panorama view and 3 PTZ views for wall mounting.	<b>〕</b>	Panorama view and 8 PTZ views.

• **Fisheye View:** In the Fisheye view mode, the whole wide-angle view of the camera displays. This view mode is called Fisheye because it approximates the vision of a fish's convex eye. The lens produces curvilinear images of a large area, while distorting the perspective and angles of objects in the image.



**Fisheye View** 

 Panorama/Dual-180° Panorama View: In the Panorama view mode, the distorted fisheye image is transformed to normal perspective image by some calibration methods.





Dual-180° Panorama View



PTZ View: The PTZ view is the close-up view of some defined area in the Fisheye view or Panorama view, and it supports the electronic PTZ function, which is also called e-PTZ. Note: Each PTZ view is marked on the Fisheye view and Panorama view with a specific navigation area with different colors. You can drag the navigation area on the Fisheye view or Panorama view to adjust the PTZ view, or drag the PTZ view to adjust the view to the desired angle.

Fisheye+3PTZ View



Panorama+3PTZ View



3. (Optional) For PTZ view, you can perform the PTZ control in the PTZ Control panel.



Select the PTZ view, and click the arrow button to adjust the image. You can click to zoom in or zoom out the view. You can click to start auto-scan.

Or you can drag in the PTZ view and scroll the mouse wheel to realize the PTZ movements. You can also drag the To set the auto-scan speed, pan speed, and tilt speed for better PTZ control.

4. (Optional) Click to enter the Circle Center Calibration interface to calibrate the circle center of the fisheye and make the fisheye expansion more accurate.



- 1) Drag the on the fisheye circle to adjust the red circle close to the fisheye view.
- 2) Click **OK** to save the calibration.

0703001061216

