

The HIKVISION logo is displayed in white, italicized, uppercase letters on a red background. The background consists of a horizontal bar with a diagonal white line on the left side, creating a stylized 'H' shape.

***HIKVISION***

**iVMS-4500 HD (Android)**

**Mobile Client Software**

**User Manual (V3.4)**

UD.6L0202D1597A01

Thank you for purchasing our product. This manual applies to iVMS-4500 HD (Android) mobile client software; please read it carefully for the better use of this software.

The contents in this manual are subject to change without notice.

## Contents

Chapter 1 Introduction.....	3
1.1 Overview .....	3
1.2 System Requirements.....	3
1.3 Conventions.....	3
Chapter 2 Installing and Uninstalling the Software.....	4
2.1 Installing the Software .....	4
2.2 Uninstalling the Software .....	4
Chapter 3 Running the Software.....	5
3.1 Interfaces Introduction.....	5
3.2 Password Protection.....	6
Chapter 4 Device Management .....	8
4.1 Adding a Device.....	8
4.2 Modifying a Device.....	9
4.3 Deleting a Device.....	10
Chapter 5 Live View .....	11
Chapter 6 Playback.....	20
Chapter 7 Alarm Management .....	24
Chapter 8 Picture & Video Management.....	27
Chapter 9 EZVIZ Cloud P2P.....	30
Chapter 10 Favorites .....	33
Chapter 11 System Configuration .....	36
Appendix .....	38
Version History .....	38

# Chapter 1 Introduction

## 1.1 Overview

iVMS-4500 HD (Android) V3.4 mobile client software, which is designed for Android Tablet on the basis of Android OS (Version 3.0 or higher), can be used to remotely monitor the live video from embedded DVR, NVR, network camera, network speed dome and encoder via wireless network, play back record files, locally store and manage pictures and videos, manage alarm notification and information, control alarm output and realize PTZ control as well.

iVMS-4500 software also provides the EZVIZ Cloud P2P service for managing your EZVIZ Cloud P2P account and the added devices.

With this software installed in your Android Tablet, you are able to log on to the front-end device via Wi-Fi, 3G or 4G; besides, if there is no public IP available for the device, it's accessible by using a dynamic name, or by mapping ports to the public IP of router.

### **Notes:**

1. Wi-Fi, 3G or 4G access service must be supported by the Tablet.
2. Network traffic charges may be produced during the use of this client software. Please refer to the local ISP.

## 1.2 System Requirements

The Tablet should be based on Android OS (version 3.0 or higher).


## 1.3 Conventions

In order to simplify the description, we define the “iVMS-4500 HD (Android) mobile client software” as “software” and “DVR, NVR, encoder, network camera, network speed dome” as “device” in the following chapters.

## Chapter 2 Installing and Uninstalling the Software

### 2.1 Installing the Software

**Steps:**


1. Log into the **Google Play**.
2. Enter “iVMS-4500 HD” to search mobile client software.
3. Download and install it to your Tablet.
4. After having installed the software successfully, you can click  to start the software.

### 2.2 Uninstalling the Software

**Steps:**


1. Enter the Application Management interface of your mobile phone (**Settings > Applications > Manage applications**).
2. Click the software icon.
3. In the Application info interface of the software, click **Uninstall** button and then click **OK** button to uninstall the mobile client software.

## Chapter 3 Running the Software






After having installed the software successfully, click  icon to run the software.


### 3.1 Interfaces Introduction

The software has six main functions, including Live View, Remote Playback, Alarm Management, Picture & Video Management, EZVIZ Cloud P2P and Configuration.



#### Icon Description

Icon	Descriptions
 <b>Live View</b>	Live view, PTZ control, local recording, alarm outputs control, etc.
 <b>Remote Playback</b>	Play back the recorded files stored in the device and clip the playback video for local management.
 <b>Alarm</b>	Enable alarm notification, manage alarm information and view the alarm linkage information.
 <b>Picture and Video</b>	Display and manage the local video files and pictures.
 <b>EZVIZ Cloud P2P</b>	Register an EZVIZ Cloud P2P account, log into your EZVIZ Cloud P2P and manage the devices which support the EZVIZ Cloud P2P service.

 <b>Configuration</b>	<b>Devices</b>	Display device list, add/delete/modify device, view device information, etc.
	<b>Favorites</b>	Define specific cameras and views to your favorites.
	<b>Local Configuration</b>	Configure password protection.
	<b>Wi-Fi Settings</b>	Configure Wi-Fi settings and generate the QR code for the Wi-Fi network.
	<b>Help</b>	Show software's help file.
	<b>About</b>	Display software's version information and main features, and configure email feedback.


### 3.2 Password Protection

With the password protection enabled, then only the user that has the password can access the software.


#### Task 1: Enable Password Protection

##### Steps:

1. Click  and select  to enter the Local Configuration interface.



2. Click the **OFF** in Password Protection item to activate password protection.




3. In the dialog box, enter the password for the software and click **Confirm** to save the settings.

Next time, if you want to run the software after closing the software, you need to enter the password to log in first.



### Task 2: Modify the Password

Click **Modify Password** and enter corresponding information to modify the password.



### Task 3: Disable Password Protection

#### **Steps:**

1. Click **ON** in Password Protection item to disable password protection.
2. In the pop-up dialog box, enter the password to confirm the settings.






## Chapter 4 Device Management


### 4.1 Adding a Device

You need to add a device firstly that all operations such as live view, playback and device management can be accessible.

**Steps:**


1. Click  and select  to enter the Device Management interface.



2. Click  to add a new device.

**Alias:** Edit a name for the device as desired.

**Register Mode:** Select the register mode to HiDDNS, IP/Domain, or IP Server.

- HiDDNS: When the device is registered on the HiDDNS server, you need to enter the HiDDNS server address and the device domain name registered on the server. You can also scan the serial No. on the label of the device by clicking  if your device has been registered on the HiDDNS server via serial No..
- IP/Domain: You can access the device through fixed IP address or domain name. You need to edit the IP address or domain address and the port of the device.
- IP Server: You can access the device through IP Server. You need to set the IP Server address, and device identifier which is the device name or device serial No..

**User Name:** Input the user name of the added device.


**Password:** Input the password of the added device.

**Camera No.:** After the device is successfully added, the number of the camera(s) under the device can be obtained when the device is online.

3. Click  to confirm the settings.

**Notes:**


- 1) If the device is successfully added, the software can obtain the camera information of the device.
- 2) Up to 256 devices can be added.
- 3) You can click **Start Live View** to live view the newly added device. Please refer to *Chapter 5* for detailed operation about live view.





Click **Devices** to return to the Device Management interface. The successfully added new device will be displayed in the Device Management interface.

## 4.2 Modifying a Device


**Steps:**


1. In the Device Management interface, select a device and click the device item to view its parameters.
2. Click  and then modify the parameters of the device according to actual needs.



3. Click  to save the modification. Or you can click **Cancel** to cancel the modification.
4. Click **Devices** to return to the Device Management interface.

### 4.3 Deleting a Device


In the Device Management interface, select a device, click the  button and click **Confirm** in the pop-up dialog box to delete the device.
















## Chapter 5 Live View

After the device is successfully added, you can view live video from the devices, enable or disable the alarm output of the device and control PTZ movement as well.

**Note:** The alarm output and PTZ control should be supported by the added device.

Click  to enter the Live View interface and the screen will be displayed in 1-division mode by default.



Icon	Description
	Hide the device node.
	Capture picture of the selected live view window.
	Record the video of the selected live view window.
	Audio control.
	Two-way audio.
	Image quality panel.
	Alarm output control panel.
	Digital zoom.
	Set favorite cameras and views.
	Stop all the live view.
	Enter full-screen mode.
	PTZ control panel.


### Start Live View

Click the device node to list all the cameras under it. Drag the camera node to the



window for live viewing. Alternatively, you can drag the device node to the window for viewing all the cameras of the device.

**Notes:**

- 1) Up to 16 cameras can be live viewed at the same time. If you drag a device node that contains more than 16 cameras for live view, then the live videos of first 16 cameras will be played.
- 2) If the channel-zero is supported by the device and it has been configured, you can select to live view channel-zero.




## Record and Capture


In live view mode, select a live viewing window and click the  to record the video of it, or click the  to capture a picture of it.

The videos and pictures can be viewed and managed in the Picture & Video Management interface (refer to *Chapter 8*).

## Image Quality

There are three defined image quality types provided, including Clear, Balanced and Fluent. And you can also customize the image quality. Click  to adjust the quality according to the performance of your network and Tablet hardware.


**Note:** If you change the image quality, the live view and recording of the device may be affected due to the new settings.



## Customize the Image Quality

**Steps:**

1. Click **Custom** to activate the customized panel shown below.



2. Configure the parameters according to actual needs, including Stream Type, Resolution, Frame Rate and Bitrate.
3. Click **Confirm** to save the settings.

**Note:** The live view effect is related to the performance of your network and Tablet hardware. If the live view is not fluent or the screen appears blurred, please reduce the resolution, frame rate and bitrate of the camera in Custom mode, or set the image quality as Balanced or Fluent mode.


The following table shows the recommended frame rate and bitrate configuration for different resolution at H.264 video compression by using Samsung Galaxy Tab P3100.

Resolution	1-ch	4-ch	6-ch	16-ch	Recommended Configuration
HD1080P	√				Frame rate: 4fps; Bitrate: 1024Kbps
UXGA	√				Frame rate: 6fps; Bitrate: 1024Kbps
XVGA	√				Frame rate: 10fps; Bitrate: 1024Kbps
HD720P	√				Frame rate: 15fps; Bitrate: 1024Kbps
4CIF	√	√			Frame rate: 25fps; Bitrate: 1024Kbps
VGA	√	√			Frame rate: 25fps; Bitrate: 512Kbps
CIF	√	√	√	√	Frame rate: 25fps; Bitrate: 256Kbps
QVGA	√	√	√	√	Frame rate: 25fps; Bitrate: 128Kbps
QCIF	√	√	√	√	Frame rate: 25fps; Bitrate: 128Kbps

## Window Division

When all the current windows are in live view, you can drag a more camera node to the live view window until the window division mode switches and then drag it to the free window for live view.

**Note:** The software supports 1 / 4 / 6 / 9 / 16-division mode.







You can drag and move the window to adjust the window sequence. Double-click the live view window to display the camera in 1-division mode and double-click again to restore.

## Stop Live View

During the live view, you can click  to stop all the live videos.

Or you can perform the following steps to stop live view of the specific camera.

1. Drag a live view window upwards, and the  will display in the top of the software.
2. Drag the window to the  until it changes to  and then release the window.




## Enable / Disable Alarm Output





You can enable or disable the alarm outputs of the added device by the software.

**Note:** The alarm output should be supported by the device.

**Steps:**

1. Click  to activate the alarm output control panel.




2. Select an alarm output  and click it to set it as  to enable this alarm output. You can also click the enabled alarm output  to set it as  to disable it.

## Digital Zoom

You can realize the partial digital zoom during live view.


### Steps:

1. Click to select a playing window.
2. Click  and the selected window will be displayed in 1-division mode.
3. Spread two fingers apart to zoom in or pinch them together to zoom out the live view.

## My Cameras and My Views


In live view mode, you can add the camera or view to the favorites so that you can access the camera or view conveniently.

### Task 1: My Cameras

Select a window that is under live view. Click  and select **My Cameras** to add the camera to My Cameras.

The successfully added camera will be listed under My Cameras node in the device nodes area. In this way, you can easily view the camera by dragging it from My Cameras node to the window area.






### Task 2: My Views

You can add the current view information to My Views.


#### Steps:

1. Click  and select **My Views**.






2. In the pop-up dialog box, edit the name for the view.
3. Click **Save** to confirm the settings.

After that, you can see the view listed under My Views node in the device nodes area. You can drag it to the window area to easily access the common view.











### PTZ Control

In live view mode, select a playing window and click  to activate PTZ control panel, and the  icon changes to .



**Note:** The PTZ control should be supported by the added device.



Icon	Description
	PTZ movements or auto-scan.
	Zoom +
	Zoom -
	Focus +
	Focus -
	Iris +
	Iris -
	PTZ steps for adjusting the pan/tilt movement speed.



### Configuring Presets

#### Steps:

1. In the PTZ control mode, use  to move the camera to the desired scene.
2. Click **Preset** to activate the preset settings interface. Click a preset and then click  under it to set the current scene as a preset.

**Note:** Up to 256 presets can be configured.



3. To call the defined preset, click the preset and then click  under it.
4. To delete the defined preset, click the preset and then click  under it.

After completion of PTZ control, click  to hide the PTZ control panel.

### Full-screen Live View

During live view, you can click  to enter the full-screen mode.

**Note:** You can touch the screen to activate the control panel after it hides.



**Icon**    **Description**



PTZ control. Slide the button to control PTZ movements.



Audio control.



Capture picture of the selected live view window.



Record the video of the selected live view window.



Stop all the live view.



Digital zoom.



Alarm output control panel.



Image quality panel.



Two-way audio.




Exit full-screen mode.


## Chapter 6 Playback

You can search the recorded video files from the remote storage device for playback.

### Start Playback

#### Steps:


1. Click  to enter the Remote Playback interface.




2. Set the start time and end time in the **From** and **To** text filed to define the search condition.
3. Drag the device node or camera node to the display window for playback.

#### **Notes:**









- 1) You can view the playback of up to 4 windows at the same time.
- 2) Only the camera with record during that period can be played back successfully.



4. In 4-division mode, you can drag and move the window to adjust the window sequence. Double-click the playback window to display the camera in 1-division mode and double-click again to restore.
5. You can slide the timeline bar to adjust the playback time of the selected window.



#### Icon Description




	Hide the device node.
	Capture picture of the selected playback window.
	Clip the playback video of the selected playback window.
	Audio control.
	Pause the playback.
	Digital zoom.
	Stop all the playback.
	Enter full-screen mode.


#### Stop Playback

There are two ways available for stopping the playback.



You can click  to stop playback of all the cameras.

Or you can perform the following steps to stop the specified playback window.

1. Drag a playback window upwards, and the  will display in the top of the software.
2. Drag the window to the  until it changes to  and then release the window.



## Clip and Capture


During the playback, select a playback window and click  to clip the playback video, or click  to capture pictures of it.

The clipped video and captured pictures can be viewed and managed in the Picture & Video Management interface (refer to *Chapter 8*).


## Digital Zoom

You can realize the partial digital zoom during playback of video files.

### Steps:

1. Select a playback window.
2. Click  and the selected window will be displayed in 1-window mode.
3. Spread two fingers apart to zoom in or pinch them together to zoom out the video.

## Full-screen Playback

During playback, click  to enter the full-screen mode. You can press and drag the control bar to adjust its position.

**Note:** You can touch the screen to activate the control bar after it hides.



### Icon



### Description

Pause the playback.



Capture picture of the playback video.



Clip the playback video.



Audio control.



Digital zoom.



Exit full-screen mode.





## Chapter 7 Alarm Management

In Alarm Management interface, you can enable alarm notification, manage alarm information, and view the alarm linked video.

### Alarm Notification

#### Steps:

1. Click  to enter the Alarm Management interface.
2. Click **Alarm Push Notification** to enter the Alarm Push Notification interface.



3. Select a device and set the  as  to enable the alarm notification of the device. In this way, the alarm information can be pushed to your Tablet at the first time.


**Note:** The device should be armed and support alarm notification.


4. When you receive a notification, it appears briefly at the top of the screen. You can ignore the notification or click it to address it right away. Otherwise, the notification displays in the alarm information directly.

### Alarm Information

#### Steps:

1. Click **Alarm Information** to enter the alarm information interface, you can view the received alarm information.




2. You can select a piece of alarm information and long press it to activate the deletion window. Click **Confirm** button to delete the alarm information.
3. If you want to clear all the alarm information, you can click .

**Notes:**


- Up to 1000 pieces of alarm information can be pushed to the alarm information list.
- The alarm supported to be pushed to the software includes motion detection alarm, video loss alarm, video tampering alarm, sensor alarm, line crossing detection alarm, intrusion detection alarm, face detection alarm, scene change detection alarm, audio exception alarm, defocus detection alarm and PIR alarm.

## Alarm Linkage

**Steps:**

1. In the alarm information interface, select a piece of alarm information and click .
2. In the pop-up message box, select **Live View** or **Remote Playback** to view the live view or record file of the camera that occurs motion detection, video loss, video tampering, line crossing, intrusion, face detection, scene change detection, audio exception, defocus detection or PIR alarm.

**Note:** The related record file will be played from 30s before the alarm occurs to 90s after the alarm. E.g., if the motion detection alarm occurred at 11:30:00, then the record file is from 11:29:30 to 11:31:30.





## Chapter 8 Picture & Video Management

In Picture and Video Management interface, you can view and manage the local video files and pictures that you manually record (clip) and capture in Live View and Remote Playback interface. The pictures and video files are stored in the iVMS-4500 HD directory of the SD card. You can also share the pictures and video files to other available applications.

The pictures and videos are displayed by date.



If you want to share the pictures and videos to other applications, please perform the following steps.

### **Steps:**

1. Click  and then select the pictures and videos you want to share.
2. Click  and select the needed application to share.




If you want to delete the pictures and videos in batch, perform the steps below.


### **Steps:**


1. You can click  and then select the pictures and videos you want to delete.
2. Click  and click **Confirm** to delete the selected file(s). Or you can click **Cancel** to cancel it.

## **Picture Management**

### **Steps:**



1. Click  to enter the Picture & Video Management interface.
2. Click a picture and the picture displays in full screen. You can click  if you want to delete it, and click  to select to share the picture to other available applications.






3. You can pinch two fingers together to zoom out or spread them apart to zoom in the picture. Or you can double-click on the picture to realize digital zoom. You can also slide to pan the picture under zoom-in mode.
4. Click  to back to the Picture & Video Management interface.



## Video Management


### Steps:

1. In the Picture & Video Management interface, click a video and the video shows in full screen. You can click  if you want to delete it, and click  to share it to other available applications.




2. Click  to play it. You can slide the timeline bar to adjust the playback time.  
 Capture a picture of the playback video.

-  Pause the playback.
-  Audio control.



## Chapter 9 EZVIZ Cloud P2P




The software also supports to register an EZVIZ Cloud P2P account, log into your EZVIZ Cloud P2P and manage the devices which support the EZVIZ Cloud P2P service.




### Register an Account

If you do not have an EZVIZ Cloud P2P account, you can register one.

#### Steps:

1. Click  to enter the EZVIZ Cloud P2P interface.
2. Click **Service Area** and select  or  according to your location.
3. Click **Register** to enter the account registration interface.  
If you select **中国服务区**: Enter your mobile phone number, click **Get Verification Code** and enter the verification code received by your mobile phone.  
If you select **International**: Enter your email account and the picture verification code. Click **Get Verification Code** and enter the verification code received by your email.



**Note:** If the picture verification code is not clear, you can click **Refresh** to get a new one.



4. Configure the user name and password for your EZVIZ Cloud P2P account to complete the registration.

## Login




### Steps:

1. Click **Service Area** and select  or .
2. Enter the user name, email account or mobile phone, input the password and click **Login**.

### Notes:

- You can check **Auto-login** checkbox to remember the user name and password log into the software automatically.
- If you forget your password, click **Forgot Password** to verify your account and reset your password.


## Device Management


1. Click  and use your Tablet to scan the serial No. on the label of your device by aligning the QR Code with the scanning frame. Or you can click  and enter the serial No. (9-bit) of the device and click  to search the device.

### Notes:

- Only the device that supports the EZVIZ Cloud P2P service can be added.
- The device can only be added to one EZVIZ Cloud P2P account.





2. The successfully added device will list on the device management interface and you can click **Start Live View** to view the live video of the device.
3. On the Devices interface, select a device and click the  to delete the device.


## Account Management

Click **Account** and you can manage your EZVIZ Cloud P2P account.

Click **Modify Password** to change the password.

Set the switch for **Auto-login** as on to enable the function.

To log out of EZVIZ Cloud P2P, you can click **Logout**.





## Chapter 10 Favorites


The **Favorites** function can be used for management of My Views and My Cameras to make the live view of commonly used cameras and views more easily and conveniently.

**My Cameras:** You can collect the commonly used cameras.

**My Views:** You can collect the commonly used views.

**Note:** For adding cameras or views to the favorites in live view mode, please refer to **Configure My Cameras and Views** in *Chapter 5*.


Click  and select  to enter the Favorites interface.






### Task 1: My Cameras

#### Steps:

1. Click **My Cameras** to enter My Cameras interface. All the cameras of the added devices will be listed.





2. The cameras that have been added to My Cameras will be marked with .
3. Click  to add the camera to My Cameras. Or click  to remove the camera from My Cameras.
4. You can click **Favorites** to return to the Favorites interface.

## Task 2: My Views

### Steps:

1. Click **My Views** to enter My Views interface. You can see all the added views.



2. You can click  to delete the view as desired.
3. For adding views to My Views, please refer to **Configure My Cameras and Views**

in *Chapter 5*.

4. You can click **Favorites** to return to the Favorites interface.

**Note:** Up to 32 views can be added to My Views.



All the successfully added cameras and views will also be listed under My Cameras node and My Views node in the device nodes area in the Live View interface.


## Chapter 11 System Configuration

### Wi-Fi Settings

The software provides the function of generating the QR code of Wi-Fi network. The network camera can scan the QR code to connect to the Wi-Fi network conveniently.

#### Steps:

1. Click  and select  to enter the Wi-Fi Settings interface.



2. Enter the Wi-Fi Name (known as SSID) and password of the Wi-Fi network, select the encryption type which should be the same as the settings of the router, and click **Generate** to generate a QR code for the Wi-Fi network.

**Note:** If you select no password as the encryption type, the password for the Wi-Fi is not required.

3. The network camera can connect to this network by scanning the QR code.


#### Notes:

- This function should be supported by the network camera.
- For detailed operation of the camera, please refer to the *User Manual* of the network camera.

4. (Optional) Click **Save** to save the Wi-Fi network and you can check it in the Wi-Fi List interface.

### Help and New Features

In the About interface, click **New Features** to view the main features of the software.

In the Configuration interface, click  to enter the Help interface. You can view the help file of the software.

## **Feedback**

If there is any problem or suggestion during you use the software, please feel free to send emails to us by clicking **Feedback** in About interface. Our technical engineers will handle your problems and suggestions as soon as possible.

## Appendix

### Version History

#### V 3.4

##### Added New Features:

1. Support local recording during live view and remote playback mode and management for captured pictures and clipped video.
2. Disable auto-lock during live view and remote playback.
3. Recover the remote playback after switching from the background.
4. Add serial No. scanning in HiDDNS register mode.
5. Support alarm notification and information management.
6. Provide EZVIZ Cloud P2P service to manage your EZVIZ Cloud P2P account and devices.
7. Support generating QR code for Wi-Fi network.
8. Up to 256 devices can be added.
9. Provide multi-language GUI. Added languages include Estonian, Japanese, Korean, Russian, Thai, Traditional Chinese, Turkish, Bulgarian, Croatian, Czech, Danish, Dutch, Finnish, French, German, Greek, Hebrew, Hungarian, Italian, Norwegian, Polish, Portuguese, Romanian, Serbian, Slovak, Slovenian, Spanish and Swedish.

#### V 3.1

##### Added New Features:

1. Support live viewing channel-zero.
2. Support customized image quality during live view mode.
3. Enable and disable alarm outputs.
4. Support audio control.
5. Preset configuration.
6. Support email feedback.
7. Support digital zoom.

#### V 3.0

##### Added New Features:

1. New designed GUI for Android Tablet provides convenient operations.
2. iPhone5 is supported.
3. Up to 16-screen live view and 4-screen playback.
4. Optimize the playing performance.
5. Display the quick operation guide and main features of the software.
6. Check new version automatically.
7. Image quality configurable during live view mode.
8. Password protection.

##### Modified:

1. Delete the Alarm Management settings.
2. Delete the channel configuration.

3. Cancel the registration when logging in for the first time.
4. Remove the setting and calling of preset.
5. Delete the function of image playback.



A graphic consisting of two overlapping rectangles. The front rectangle is red and tilted slightly counter-clockwise. The back rectangle is light grey and tilted slightly clockwise, partially obscured by the red one.

First Choice for Security Professionals