

[12] CLOSING (ARMING) REPORTING CODES FOR ACCESS CODES 9 TO 16

ACCESS CODE 9
 ACCESS CODE 10
 ACCESS CODE 11
 ACCESS CODE 12
 ACCESS CODE 13
 ACCESS CODE 14
 ACCESS CODE 15
 ACCESS CODE 16

| | |
|--|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

[13] OPENING (DISARMING) REPORTING CODES FOR ACCESS CODES 1 TO 8

ACCESS CODE 1
 ACCESS CODE 2
 ACCESS CODE 3
 ACCESS CODE 4
 ACCESS CODE 5
 ACCESS CODE 6
 ACCESS CODE 7
 ACCESS CODE 8

| | |
|---|--|
| 2 | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

[14] OPENING (DISARMING) REPORTING CODES FOR ACCESS CODES 9 TO 16

ACCESS CODE 9
 ACCESS CODE 10
 ACCESS CODE 11
 ACCESS CODE 12
 ACCESS CODE 13
 ACCESS CODE 14
 ACCESS CODE 15
 ACCESS CODE 16

| | |
|---|---|
| 4 | 2 |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

[15] MISCELLANEOUS FUNCTIONS REPORTING CODES

PARTIAL CLOSING***
 KEYPAD PANIC ALARM [P]*
 KEYPAD FIRE ALARM [F]*
 KEYPAD EMERGENCY ALARM [A]*
 KEYPAD PANIC RESTORAL [P]*
 KEYPAD FIRE RESTORAL [F]*
 KEYPAD EMERGENCY RESTORAL [A]*
 PERIODIC TEST TRANSMISSION**

| | |
|--|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

- * Priority alarms/restoral
- ** Maintenance alarms/restoral see section [33]
- ***Transmission reports with section [11] & [14] (openings closings)

[16] ZONE DEFINITIONS FOR ZONES 1 TO 8

FACTORY PROGRAMME (DEFAULT)

| | | |
|--------|--------------------------|--------------------------|
| ZONE 1 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 2 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 3 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 4 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 5 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 6 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 7 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 8 | <input type="checkbox"/> | <input type="checkbox"/> |

1ST DIGIT
 0= SLOW,AUDIBLE
 1= SLOW, SILENT
 2= FAST, AUDIBLE
 3= FAST, SILENT

2ND DIGIT
 0= DELAY
 1= INSTANT
 2= INTERIOR
 3= INTERIOR... HOME/AWAY
 4= 24HR...BELL
 5= 24HR...BELL/BUZZER
 6= 24HR...BUZZER
 7= DOUBLE DELAY
 8= 4x DELAY
 9= FOIL

| | |
|---|---|
| 0 | 0 |
| 0 | 1 |
| 0 | 1 |
| 0 | 1 |
| 0 | 1 |
| 0 | 1 |
| 0 | 1 |
| 0 | 1 |

[17] ZONE DEFINITIONS FOR ZONES 9 TO 16

| | | |
|---------|--------------------------|--------------------------|
| ZONE 9 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 10 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 11 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 12 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 13 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 14 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 15 | <input type="checkbox"/> | <input type="checkbox"/> |
| ZONE 16 | <input type="checkbox"/> | <input type="checkbox"/> |

1ST DIGIT
 0= SLOW,AUDIBLE
 1= SLOW, SILENT
 NOTE.....
 ZONES 9 - 16 CANNOT BE PROGRAMMED FOR FAST RESPONSE - DO NOT USE FAST RESPONSE DEVICES ON THESE LOOPS. (eg. Vibration Detectors)

2ND DIGIT
 0= DELAY
 1= INSTANT
 2= INTERIOR
 3= FUTURE USE *Home Arming*
 4= 24HR...BELL
 5= 24HR...BELL/BUZZER
 6= 24HR...BUZZER
 7= DOUBLE DELAY
 8= 4x DELAY
 9= FOIL

| | |
|---|---|
| 0 | 1 |
| 0 | 1 |
| 0 | 1 |
| 0 | 1 |
| 0 | 1 |
| 0 | 1 |
| 0 | 1 |
| 0 | 1 |

[18] 1ST SYSTEM OPTION CODE

| | |
|--------------|--------------------------|
| ZONE LIGHT 1 | <input type="checkbox"/> |
| ZONE LIGHT 2 | <input type="checkbox"/> |
| ZONE LIGHT 3 | <input type="checkbox"/> |
| ZONE LIGHT 4 | <input type="checkbox"/> |
| ZONE LIGHT 5 | <input type="checkbox"/> |
| ZONE LIGHT 6 | <input type="checkbox"/> |
| ZONE LIGHT 7 | <input type="checkbox"/> |
| ZONE LIGHT 8 | <input type="checkbox"/> |

| ZONE LIGHT ON | ZONE LIGHT OFF |
|---------------------------|------------------------|
| COMMUNICATION DISABLED | COMMUNICATION ENABLED |
| RESTORALS ON BELL TIMEOUT | RESTORALS ON DISARMING |
| ALARM DISPLAY WHILE ARMED | NO ALARM DISPLAY/ARMED |
| DTMF DIALING | PULSE DIALING |
| N/C LOOPS | EOL RESISTORS LOOPS |
| KEYPAD [P]ANIC AUDIBLE | SILENT |
| CALL 1ST PHONE ONLY | BACK UP TO 2ND PHONE |
| 16TH CODE = MAID'S CODE | NORMAL CODE |

| |
|-----|
| OFF |
| OFF |
| OFF |
| OFF |
| OFF |
| ON |
| OFF |
| OFF |

[19] 2ND SYSTEM OPTION CODE

| | |
|--------------|--------------------------|
| ZONE LIGHT 1 | <input type="checkbox"/> |
| ZONE LIGHT 2 | <input type="checkbox"/> |
| ZONE LIGHT 3 | <input type="checkbox"/> |
| ZONE LIGHT 4 | <input type="checkbox"/> |
| ZONE LIGHT 5 | <input type="checkbox"/> |
| ZONE LIGHT 6 | <input type="checkbox"/> |
| ZONE LIGHT 7 | <input type="checkbox"/> |
| ZONE LIGHT 8 | <input type="checkbox"/> |

| ZONE LIGHT ON | ZONE LIGHT OFF |
|---------------------------------|------------------------|
| SEND OPENING AFTER ALARM | SEND OPENING NORMALLY |
| MASTER CODE NOT CHANGEABLE | MASTER CODE CHANGEABLE |
| BELL SQUAWK ENABLED (1) | BELL SQUAWK DISABLED |
| PC16 OUT ENABLED | PC16 OUT DISABLED |
| TLM TROUBLE ONLY <i>Key pad</i> | NORMAL |
| 1400Hz RADIONICS | 2300Hz RADIONICS |
| TLM DISABLED | TLM ENABLED |
| USER CODE REQ'D FOR SHUNT | USER CODE NOT REQ'D |

| |
|-----|
| OFF |
| OFF |
| OFF |
| OFF |
| OFF |
| OFF |
| OFF |
| OFF |

(1) WITH BELL SQUAWK ENABLED - the siren/bell will sound one short burst on arming and two short bursts on disarming.

[20] ZONES 1 TO 8 BY-PASS (SHUNT) MASK

| | |
|--------------|--------------------------|
| ZONE LIGHT 1 | <input type="checkbox"/> |
| ZONE LIGHT 2 | <input type="checkbox"/> |
| ZONE LIGHT 3 | <input type="checkbox"/> |
| ZONE LIGHT 4 | <input type="checkbox"/> |
| ZONE LIGHT 5 | <input type="checkbox"/> |
| ZONE LIGHT 6 | <input type="checkbox"/> |
| ZONE LIGHT 7 | <input type="checkbox"/> |
| ZONE LIGHT 8 | <input type="checkbox"/> |

NOTE.....
IF ZONE LIGHT IS ON,
THE ZONE CAN BE BY-PASSED
USING THE [*][1] COMMAND)

| |
|----|
| ON |
| ON |
| ON |
| ON |
| ON |
| ON |
| ON |
| ON |

[21] ZONES 9 TO 16 BY-PASS (SHUNT) MASK

| | |
|---------------|--------------------------|
| ZONE LIGHT 9 | <input type="checkbox"/> |
| ZONE LIGHT 10 | <input type="checkbox"/> |
| ZONE LIGHT 11 | <input type="checkbox"/> |
| ZONE LIGHT 12 | <input type="checkbox"/> |
| ZONE LIGHT 13 | <input type="checkbox"/> |
| ZONE LIGHT 14 | <input type="checkbox"/> |
| ZONE LIGHT 15 | <input type="checkbox"/> |
| ZONE LIGHT 16 | <input type="checkbox"/> |

NOTE.....
IF ZONE LIGHT IS ON,
THE ZONE CAN BE BY-PASSED
USING THE [*][1] COMMAND

| |
|----|
| ON |
| ON |
| ON |
| ON |
| ON |
| ON |
| ON |
| ON |

[22] SYSTEM TIMES

ENTRY DELAY TIME (IN SECONDS)
EXIT DELAY TIME (IN SECONDS)
BELL CUT-OFF TIME (IN MINUTES)
AC FAILURE TRANSMISSION DELAY (IN MINUTES)
NORMAL LOOP RESPONSE TIME (X 10 MSEC)
TEST TRANSMISSION CYCLE TIME (IN DAYS)

| | |
|----------------------|----------------------|
| <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> |

29

VALID ENTRIES ARE: 01 TO 99

* DO NOT ENTER "00" - IT IS NOT A VALID ENTRY

| | |
|---|---|
| 3 | 0 |
| 4 | 5 |
| 0 | 4 |
| 0 | 1 |
| 5 | 0 |
| 0 | 1 |

[23] SYSTEM CLOCK TIMES

AUTOMATIC ARMING TIME OF DAY
AUTOMATIC DISARMING TIME OF DAY
TEST TRANSMISSION TIME OF DAY

| | | | |
|----------------------|----------------------|----------------------|----------------------|
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |

ENTER 4 DIGITS 00 TO 23 HOURS
00 TO 59 MIN.

IF NOT USED LEAVE AT THE FACTORY DEFAULT SETTINGS.

| | | | |
|---|---|---|---|
| 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 |

[24] NEW INSTALLER'S CODE

[25] NEW MASTER CODE

[26] DOWNLOADING ACCESS CODE

(ENTER 4 DIGITS FROM 0 TO 9 DO NOT ENTER [*] OR [#])

| | | | |
|----------------------|----------------------|----------------------|----------------------|
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |

| | | | |
|---|---|---|---|
| 3 | 0 | 0 | 0 |
| 1 | 2 | 3 | 4 |
| 3 | 0 | 3 | 0 |

[27] COMMUNICATOR FORMAT OPTIONS

1ST TELEPHONE NUMBER
2ND TELEPHONE NUMBER

| |
|--------------------------|
| <input type="checkbox"/> |
| <input type="checkbox"/> |

IT IS NECESSARY TO PROGRAM
FORMAT FOR BOTH NUMBERS.

| |
|---|
| 1 |
| 1 |

ENTER ONE HEX DIGIT FROM [0] TO [F] FOR EACH PHONE NUMBER FROM LIST:

- [0] SILENT KNIGHT/ADEMCO SLOW, 10 BPS (1400HZ HANDSHAKE) 3/1, 3/2 AND 4/1, 4/2 NON EXTENDED FORMAT
- [1] SESCOA, FRANKLIN, DCI, VERTEX, 20 BPS (2300HZ HANDSHAKE) 3/1, 3/2 AND 4/1, 4/2 NON EXTENDED FORMAT
- [2] SILENT KNIGHT FAST, 20 BPS (1400HZ HANDSHAKE) 3/1, 3/2 AND 4/1, 4/2 NON EXTENDED FORMAT
- [3] RADIONICS, (2300/1400HZ* HANDSHAKE) 3/1, 4/2 NON EXTENDED FORMAT
- [4] RADIONICS, (2300/1400HZ* HANDSHAKE) 3/1, 4/2 NON EXTENDED WITH PARITY FORMAT
- [5] SESCOA SUPER SPEED

